



SPEED OF SOUND

1994-2004 Mustang Center Armrest Gauge/Switch Panels

Installation Instructions

Please accept our thanks for choosing this product for your car. Your new panel has been manufactured for years of reliable service, right here in the USA. This panel is not formed or stamped, but is CNC machined for excellent durability. Quality materials provide rugged performance with "Hey, that's cool!" styling.

These instructions cover the installation of this panel into your factory center armrest console bin location. Due to the many different variations and manufacturers of gauges and switched devices, we cannot advise how to handle those aspects of this installation. Consult your manufacturer's provided instructions for best results in wiring your chosen applications.

To remove the armrest console bin in a 1994-2000 car:

- **Open the armrest cover**
- **Locate the rubber "bumpers" the cover rests on, and remove them carefully. They will pull free with minimal effort**
- **Under these rubber stops, you will find the mounting screws for the bin. Use a small Phillips head screwdriver and remove the screws, and place them in an area where they won't be lost.**
- **Lift the console bin out of the car in order to access your accessory wiring from your chosen devices.**
- **Drill a small hole(s) in the bottom of the bin to allow the wiring to pass upwards towards the switch panel.**
- **Terminate the wiring and drop the SOS panel into the bin.**

To remove the armrest console bin in a 2001-2004 car:

- **Open the armrest cover**
- **Remove the screws from the floor of the console bin**
- **Pull the panel free, not much force is required to release the mounting clips**
- **Unplug the 12 Volt receptacle**
- **Drill a small hole(s) in the bottom of the bin to allow the wiring to pass upwards towards the switch panel.**
- **Insert bin back into console, replace screws**
- **Terminate the wiring and drop the SOS panel into the bin. Our**